

Installation instruction

FLEX – products

Installation instructions for Purus FLEX-products with stepless adjustment to correct height. Related products: FLEX, FLEX outlet, FHP/FLEX Extension and FHP/FLEXI Extension.



Measure desired height



Unscrew the upper part



Cut the lower part at the upper edge as much as required.



Reassemble. Press and screw the two parts together. Check the height.

If the desired height is not attained

1. The gully/Extension ring is still too high. Do the above actions once again and cut more height.
2. The gully/Extension ring too low. Turn the upper part counterclockwise once. Equal to 5 mm. Check so that the upper part is fastened to the lower part.

Refers to:

ART. no 711 35 91	- FLEX
ART. no 711 35 92	- FLEX Outlet
ART. no 713 36 49	- FHP FLEX
ART. no 713 36 50	- FHP FLEXI